



## NEDERLANDS

Deze systemen kun je vinden aan de wand onder of achter de whiteboard in de zaal of in de teacher desk.

### Aanzetten Systeem

1. Druk op de "ON" knop om het systeem op te starten.  
Wacht tot het "ON" lichtje gestopt is met knipperen.

### Invoerbron selecteren

2. Druk op de knop PC, LAPTOP of HDMI (laptop). Een laptop kan worden aangesloten met VGA- of de HDMI-kabel.

### Uitzetten systeem

3. Druk op de "OFF" knop om het systeem uit te zetten.

## Overige opties

### Volumeregeling

Draai rustig aan de volume knop. De volumeknop werkt met lichte vertraging.

### Overige sturingsknoppen

PIC MUTE: beamerscreen uit

Lamp-symbool: Eerste rij verlichting aan/uit

Scherm-symbool: Scherm omhoog/omlaag

## ENGLISH

You can find these systems on the wall or behind the whiteboard in the room or in the teacher desk.

### System startup

Press the "ON" button to start up the system. Wait for the "ON" light to stop blinking.

### Select source

Press the PC, LAPTOP or HDMI (laptop) Button. You can connect a laptop with the VGA- or the HDMI-cable.

### System shutdown

Press the "OFF" button to shutdown the system.

## Additional options

### Volume control

Turn the volume button slowly. The volume button has a slight delay.

### Additional control buttons

PIC MUTE: Beamer screen off/on

Lamp symbol: Front lights on/off

Screen symbol: Screen up/down



### Assistentie nodig?

Neem contact op met servicedesk FS via toestelnummer "1403".

Je krijgt binnen enkele seconden een medewerker van de Servicedesk aan de lijn.

### Need assistance?

Please contact the servicedesk FS through phone number "1403". In seconds you will be assisted by employees of the Servicedesk.